

Settings (Remote Control MH01)

Button	Remarks		
ONOFF	Press the "ON/OFF" button, the light goes to constant on or constant off mode, sensor is disabled. Press " Reset " or " Auto Mode" button to quit from this mode.		
Reset	Press "Reset" button, all parameters are same as setting of DIP switch.		
Auto Mode	Press "Auto Mode" button, the sensor starts to work and all parameter setting will be remained the same as the previous status before the light was switched on/off.		
DIM Test	Press "DIM Test" button to test dimming function. Sensor will dim automatically and return to normal work mode.		
Test (2s)	The button "Test(2s)" is for factory testing purpose only. The sensor will go to test mode, Detection sensitivity: 100% Hold time: 2sec stand-by dim level:10% Stand-by period: 0s Daylight sensor: Disable Test mode can be quit by pressing any button.	Sand-by DML evel 10% 20% 30% 50% Sand-by Period 10 10s 1min 3min 5min 40min 30min 400 Daylight Sensor 11LLE 150LLE 50LLE 100LLE 50LLE	
QS1 QS2 QS3 QS4	scene Detection Hold Stand-by Stand-by Daylight Options Area Time period dim level Sensor		
	QS1 100% 30s 1min 10% 5Lux		
	QS2 100% 1min 3min 10% 10Lux		
	QS3 100% 5min 10min 10% 30Lux		
	QS4 100% 10min 30min 10% Disable		
	Note: Detection area / Hold time /Stand-by period / Stand-by dim level / Daylight sensor can be adjust by pressing corresponding button. The latest setting stays in validity.		

As the control angle of the Infrared Remote Control is fixed (15°), if sensors are installed too close to each other, settings of both sensors will be configured. Please refer to the below chart for the distance of the installation of the sensor:

Mounting height	Distance between sensors	
15m	4m	
12m	3.4m	
9m	2.4m	
6m	1.6m	
3m	0.8m	

