



**WARNING-RISK OF FIRE MOST DWELLINGS
BUILT BEFORE 1985 HAVE SUPPLY WIRE RATED 60°C
CONSULT A QUALIFIED ELECTRICIAN BEFORE INSTALLING.**
**INSTALLATION INSTRUCTIONS AND TEMPLATE
FOR 6" REMODEL HOUSING**

1. USING TEMPLATE, SCRIBE CIRCLE ON CEILING IN DESIRED LOCATION.
2. ACCURATELY CUT HOLE IN CEILING.
3. PROVIDE ELECTRICAL SERVICE WITH FLEXIBLE CABLE ONLY.
PASS CABLE THROUGH OPENING AND WIRE FIXTURE IN ACCORDANCE
WITH NEC OR YOUR LOCAL ELECTRICAL CODE.
4. WITH CLIPS SEATED PROPERLY IN CAN (FIG. 1).
5. HOLD FIXTURE UP AGAINST CEILING, JUNCTION BOX FIRST.
INSERT REMODEL HOUSING INTO CEILING, PUSH CLIP THROUGH HOUSING
SLOT (FIG. 2).
6. TO LOCK CLIP IN PLACE PUSH FLAT PORTION AGAINST SIDE OF CAN (FIG. 2).
7. TO RELEASE PULL DOWN ON CLIP (FIG. 3).
8. INSTALL TRIM.

