




Questions?

For customer service please call us at 1-310-787-1100
Office Hours: 8:00 a.m. – 5:00 p.m. PST Monday-Friday
E-mail: info@eurilighting.com



LED Parking Garage Light

PLEASE REVIEW THE INSTRUCTIONS AND WARNINGS LISTED BELOW PRIOR TO PROPER INSTALLATION

WARNINGS

- Do not use the electric generator to test the LED lamp.
- Please abide by related country, regional and local law and regulations when installing this fixture.
- Please turn off the power before installation or maintenance.
- Proper earth grounding is required to ensure safety.

WARNING/ AVERTISSEMENT


MIN 75°C SUPPLY CONDUCTOR

THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.

IMPORTANT

- Please check if there is any damage during shipping. If so, please contact manufacturer immediately.
- Please read the installation instructions carefully to check whether all the accessories are complete. After confirmation, install the fixture according to installation steps.

WIRING DIAGRAM



INSTALLATION (1)

- Disassemble the driver box cover.
- Loosen the 3/4 plug on the driver box cover by screwdriver.
- Fix the driver box cover on the 3/4 tube.
- Cling the safety rope in the driver box to the hook inside the driver box.
- Connect the input line and ground; If the fixture is equipped with sensors, adjust the sensor settings. Take relevant waterproof measures after the wires are connected.
- Align the drive box cover with the metal shrapnel inside the drive box and press upward to fasten it together.
- Lock the four screws, the product is installed.


INSTALLATION (2)

- Disassemble the driver box cover.
- Loosen the 3/4 plug on the driver box cover by screwdriver.
- Drill the holes on the ceiling according to fit the plate.
- Fix the driver box cover on the ceiling.
- Cling the safety rope in the driver box to the hook inside the driver box.
- Connect the input line and ground; If the fixture is equipped with sensor, adjust the sensor settings; Take relevant waterproof measures after the wires are connected.
- Align the drive box cover with the metal shrapnel inside the drive box and press upward to fasten it together.
- Lock the four screws, the product is installed.



Questions?

For customer service please call us at 1-310-787-1100
Office Hours: 8:00 a.m. – 5:00 p.m. PST Monday-Friday
E-mail: info@eurilighting.com



LED Parking Garage Light


PLEASE REVIEW THE INSTRUCTIONS AND WARNINGS LISTED BELOW PRIOR TO PROPER INSTALLATION

INSTALLATION (3)


- 1** Disassemble the driver box cover.
- 2** Loosen the 3/4 plug on the driver box cover by screwdriver.
- 3** Drill holes on the ceiling.
- 4** Fix the upper bracket on the ceiling.
- 5** Fix the lower bracket on the driver box cover.
- 6** Align with the holes of upper and lower bracket; tighten with screws.
- 7** Cling the safety rope in the driver box to the hook inside the driver box.
- 8** Use M20 waterproof connector when connecting AC wire or dimming wire, take relevant waterproof measures at both sides of inlet.
- 9** Connect the input line and ground; If the fixture is equipped with sensor, adjust the sensor settings; Take relevant waterproof measures after the wires are connected.
- 10** Align the drive box cover with the metal shrapnel inside the drive box and press upward to fasten it together.
- 11** Lock the four screws, the product is installed.

COLOR TEMPERATURE SWITCH

- Move the switch left and right to get the desired color temperature.




STRUCTURE OF MOTION SENSOR




PARAMETER SETTING BY REMOTE CONTROL IN MANUAL OF RC-100 WIRING DIAGRAMS

- BR1823-B-D wiring with dimming ballast or LED driver.
Dimming Driver



- BR1823-B-D wiring with non-dimming ballast or LED driver.
Non-Dimming Driver



RECOMMENDED DIMMER LIST

LUTON: NTSTV-DV / LEVITON: DS710-10Z / LEVITON: IP710 / Legrand: RH4FBL3PW