

INSTALLATION INSTRUCTIONS

LED VANITY

Input Volt. 120VAC/60Hz, Dimmable

READ AND FOLLOW SAFETY INFORMATION

Turn off the main power at the circuit breaker before installing and servicing the fixture to prevent possible injury from electric shock. All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections, obtain the services of a qualified electrician.

INSTALLATION & ASSEMBLY

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

1. Place the mounting wall plate(3) over the outlet box(1), align the mounting slots of the wall plate with holes of the outlet box as shown. Use a level to ensure the wall plate(3) is straight.
 2. Mark the location of the keyhole slots of the wall plate on the wall. Drill a 1/8" holes at the narrow end of each keyhole slot marking on the wall. Carefully hammer a wall anchor into each drilled hole.
 3. Replace the mounting wall plate(3) over outlet box, align the narrow end of each keyhole slot with its respective wall anchor. Feed the anchor screws (8) through keyhole slots and thread them into the wall anchors until wall plate is flush against the wall. Additionally, fasten the wall plate to thread holes in outlet box using two outlet box screws, as shown.
 4. *Pull the supply wires (4 & 5) and house ground wire (6) out from the outlet box (1) before attaching wall plate to outlet box.*
Make electrical connections, connect the black fixture black wire (10) to the black supply wire (5) and the white fixture wire (9) to the white supply wire (4) using wire nut (7). Connect the fixture ground wire (11) to the supply ground wire (6) together using wire nut (7). Wrap all wire connections with electrical tape to ensure secure connection.
 5. Place the fixture base (13) over the mounting wall plate (3) and secure it to the wall plate by using four fixture screws (12).
 6. Installation complete, restore power at the circuit breaker and turn light switch on to activate this fixture.
- Care and maintenance – Use dry and clean cloth to wipe the surface of the fixture.
Replacement- This LED product has no bulb to replace.



RP LIGHTING • FANS

COMPATIBLE DIMMERS :

Product Family	Dimmer Brand	Dimmer Model#
4906BN-18 4906BN-24	Lutron	DVELV-300P
		SELV-300P
	Leviton	AYCL-153P
		SCL-153P
4906BN-36 4906BN-48	Lutron	DSL06
		RHL06
	Leviton	DVELV-300P
		SELV-300P
		AYCL-153P
		SCL-153P
		DSL06
		6672

• **Five Years limited Warranty** •

RP Lighting warrants this product to be free from defects in material and workmanship for five years from the original date of purchase by the consumer. This warranty is limited to the counter replacement at the time of purchase with the original receipt. We will not be liable for the loss or damage of any kind, incidental or consequential damages of any kind, whether based on or negligence and arising in connection with the sale, use or repair of the product. claimed to be defective. Some states do not allow the exclusion or limitation of incidental or consequential damages so above limitation may not apply to you. This warranty gives you specific legal right and you may also have other rights, which vary from state to state. Misuse, improper installation, accidental installation or maintenance will void warranty.

1. OUTLET BOX (EXCLUDED)
2. OUTLET BOX SCREWS
3. MOUNTING WALL PLATE
4. WHITE SUPPLY WIRE
5. BLACK SUPPLY WIRE
6. HOUSE GROUND WIRE
7. WIRE NUTS
8. ANCHOR SCREWS
9. WHITE FIXTURE WIRE
10. BLACK FIXTURE WIRE
11. FIXTURE GROUND WIRE
12. FIXTURE SCREWS
13. FIXTURE BASE